

Login

Type the default ip address 10.0.0.1 or if you have already setup wifi.

Analytics engine skyspark's default login is:

User name: su

Password : 19may1919

Change the password to your liking as soon login in.